

Link do produktu: <https://www.nobshop.pl/odbiornik-matek-expresslrs-elrs-r24-d-24ghz-diversity-receiver-p-3184.html>

Odbiornik Matek ExpressLRS ELRS-R24-D 2.4GHz Diversity Receiver



Cena brutto	92,00 zł
Cena netto	74,80 zł
Dostępność	Aktualnie niedostępny
Czas wysyłki	1 - 3 dni
Kod producenta	ELRS-R24-D
Producent	Matek Systems

Opis produktu

ELRS-R24-D Specifications

- ESP8285, SX1280/1281IMLRT
- PA/LNA: SE2431L
- Antenna connector: IPEX MHF 1
- RF Frequency: 2.4GHz (2400~2480MHz)
- Telemetry power: 22.5dbm~23dbm
- SE2431L RX_gain: 12.5dB
- Diversity (antenna-switching), default ANT2
- Receiver protocol: CRSF
- Input voltage: 4~9V DC @ 5V pad
- Power dissipation: 40~45mA(before binding), 70~75mA(binding), 90~95mA(wifi mode)
- PCB size: 21mm x 15mm
- Weight: 3g w/ 2x antennas
- Packing: 1x ELRS-R24-D, 2x IPEX MHF1 Antennas

Firmwares

- **ExpressLRS MATEK_2400_RX** <http://www.mateksys.com/?portfolio=elrs-r24#tab-id-4>
- Firmware update via UART or WIFI
- ELRS-R24-D: enable "USE_DIVERSITY" (checked) when flashing in ExpressLRS configurator

TIPS

- **"Any ELRS 2.4Ghz receivers can work with any ELRS 2.4Ghz TX Modules, from any manufacturer and even the DIY ones. This is as long as they have the same binding phrase and configuration options (Regulatory Domain, Performance Options and Extra Data)."**
- More details about ExpressLRS, pls check out [ExpressLRS wiki](#)

Wiring with FC

- Receiver RX — FC UART_TX for Telemetry
- Receiver TX — FC UART_RX for Control
- Receiver 5V — FC 5V or 4v5

- Receiver G — FC GND
- Receiver protocol: Serial-based receiver – CRSF

Traditional Binding

• **Receivers have ExpressLRS fw preloaded without BINDING_PHRASE**

1. Power on and off your receiver three times
2. Make sure the LED is doing a quick double blink, which indicates the receiver is in bind mode
3. Use the [BIND] button on the Transmitter Lua script, which sends out a binding pulse
4. Receiver will switch to slow blink once it has received binding pulse.
5. Power off and power on receiver again. If the receiver LED switch to solid on from slow blink, it's bound with your transmitter.

- **Important: If the RX firmware has a bind phrase, the RX will never enter binding mode using the above procedure. It must be flashed without a binding phrase to do traditional binding.**

Flashing with ESP_NodeMCU-PyFlasher

1. Connect receiver to USB-TTL module(RX-TX, TX-RX, 5V-5V, G-GND)
2. Connect USB to PC while pressing and holding the boot button in.
3. open ESP_NodeMCU-PyFlasher
4. select **Serial port** of USB-TTL module, load firmware, select “**Dual Output(DOUT)**” and “**Yes.wipes all data**”
5. click “**Flash NodeMCU**”
6. after flashing, Power off and power on your receiver, receiver will enter binding mode(quick double blink).

Flashing with ELRS configurator

- MATEK_2400_RX target is supported by ELRS configurator 1.1.0 with fw release 1.2.0 or newer.

Comparison in ELRS-R24 series

SKU	R24-P	R24-D	R24-S
RF Frequency	2.4GHz	2.4GHz	2.4GHz
Antenna	IPEX MHF1	2x IPEX MHF1□ Diversity	SMT Antenna
PA/LNA	/	SE2431L	AT2401C
Telemetry	12dbm	23dbm	20dbm
LNA	/	12.5dB	12dB
Rx_gain			
CRSF	DIY_2400_RX_ESP828	MATEK_2400_RX	MATEK_2400
Serial receiver	5_SX1280		_RX
PWM receiver	MATEK_2400_RX_PWM	/	/

Comparison between ELRS-R24-P and CRSF-PWM converter

SKU	R24-P	CRSF-PWM-6	CRSF-PWM-C
	Receiver with ELRS direct PWM output	CRSF to PWM Converter/Decoder	
PWM	5	6	10

outputs		
RF	2.4GHz	compatible with any CRSF
Frequency		protocol receivers
		(including 433MHz, 868MHz,
		915MHz, 2.4GHz)
PWM	50Hz	50, 100, 160, 330, 400Hz
frequency		
Telemetry	RSS, Qly SNR	RSSI, Qly SNR
ID		RxBt, Curr, Capa, Bat%, GPS,
		GSpd, Hdg, Alt, Sats
CH	support	No
remapping		