

Link do produktu: <https://www.nobshop.pl/micro-odbiornik-dsmx-p-1385.html>

Micro odbiornik DSMX



www.nobshop.pl

Cena brutto	75,00 zł
Cena netto	60,98 zł
Dostępność	Aktualnie niedostępny
Czas wysyłki	1 - 3 dni

Opis produktu

Note: The DSMX micro receiver (white color) shown above is now replaced by the new DSMX micro receiver (black color). The binding procedure of both micro receivers is same.

Specification

- Input power: 5V
- Frame rate: 22ms/11ms
- Resolution: 2048
- Working current: 60MA
- Weight: 0.6 g
- Receive sensitivity: -108DBM
- Delay: <15ms
- Antenna length: 80MM Antenna
- Data format: DSMX
- Distance: 300m
- Channels: support 6-8 channels
- Compatible Transmitters: DSM2 / DSMX series of remote transmitter

This is the connection diagram with on the [2S Whoop FC board](#) on Beta65X and Beta75X.

Binding Procedure

- Connet the receiver to FC and run the Betaflight. On Betaflight GUI, configure the **UART1 port** to serial port in Ports tab. Then click the Save and Reboot button in the lower right corner.
- In the Configuration tab, for Receiver Mode, choose Serial_based receiver (SPEKSAT, SBUS, SUMD); Serial Receiver Provider, choose **SPEKTRUM2048**. And click the Save and Reboot button in the lower right corner.
- Type: **set spektrum_sat_bind=9** in CLI and save.
- Repower the receiver. The light on the receiver will flash rapidly, which means it's on binding mode.
- Turn on the radio and select bind mode. Wait a moment. It means bind successfully if the light on receiver keeps brighting.

Package

- 1 * BETAFPV Micro DSMX Receiver (Include antenna)
- 1 * Clear heatshrink tubing
- 1 * Silicone Wire (Black)
- 1 * Silicone Wire (Red)

-
- 1 * Silicone Wire (Yellow)

□